

# Conformal Coating on PCBAs

Technical Whitepaper No. 200



640 N. Prospect Dr.  
Whitewater, WI USA 53190  
262-458-1000 | F: 262-458-1010  
ueinc.com

## KEY TAKEAWAY

### Why Conformal Coat?

The function of circuit assemblies can deteriorate due to external factors such as moisture, salt spray, chemicals, and temperature extremes. Conformal coatings can be used in a wide range of environments to protect against damaging effects like corrosion, mold growth, and electrical failures caused by outside agents. This protection can then permit a tighter conductor spacing which allows engineers the ability to create more compact designs without sacrificing reliability. Conformal coating can therefore yield the same environmental protection as potting with the added advantage of rework ability; still, potting does increase the durability of the electronic assembly while still allowing for some level of repair or rework.

### What is a Conformal Coat?

Conformal coat is a protective coating that conforms to the electronic assembly, and they can be derived from several different compounds. The types of coatings detailed below are considered one part and are the most commonly used coatings in the electronics industry. They are categorized here by resin base. These materials provide differing levels of resistance to environmental conditions but are all semi-permeable and do not fully waterproof and seal the electronic assembly. The operational requirements of the electronics will determine the proper coating choice for your application.


### Types of Conformal Coats

Type	Solvent Resistance	Electrical Resistance	Rework Ability	Temperature Operating Range	Cost
Acrylic	Poor	Good	Easy	Good	Low
Polyurethane	Best	Great	Impossible	Good	Low
Silicone	Better	Great	Hard	Widest	High

**Acrylic** - Acrylic coatings provide the least protection of any of the coatings discussed here but are distinguished from other coatings by ease of removal. This coating can be removed by a variety of solvents, making economical rework and even field repair. Acrylic coatings are easy to work with and dry quickly through solvent evaporation at room temperature, and they are good in applications requiring moisture protection against elements like high humidity and salt spray. Although they are not suitable in applications requiring chemical resistance, they do provide high dielectric strength and operate well in a wide temperature range while still maintaining flexibility. These coatings are popular in marine, consumer electronics, and some medical industries.



**Polyurethane** - This coating is known for excellent moisture and chemical resistance. However, this quality makes repair and reworking of the coated electronics a challenge. Polyurethane operates well in a wide temperature range and maintains flexibility at very low temperatures and is popular in industries like aerospace, automotive, and medical.



**Silicone** - The differentiator between silicone coatings and the others discussed here is solid chemical, moisture and salt spray resistance over the widest temperature range. Silicone coatings excel in high humidity environments like outdoor applications. A silicone coating provides the highest chemical resistance and protection in extreme environments, and they are ideal for high/low temperature applications requiring maximum flexibility. Silicone is popular in industries like aviation, consumer electronics, and energy.



## Methods of Coating Application

Method of Application	Method	Speed of Application	Accuracy of Application	Process Control (Repeatability)	Labor Cost
<b>Manual (Brush)</b>	<i>Applied by hand with brush</i>	<i>Slow</i>	<i>Good</i>	<i>Poor</i>	<i>High</i>
<b>Hand-Spray</b>	<i>Manually with a sprayer</i>	<i>Fastest</i>	<i>Poor</i>	<i>Poor</i>	<i>Lowest</i>
<b>Machine (Aerosol)</b>	<i>Material mixed with air and/or gas</i>	<i>Moderate</i>	<i>Good</i>	<i>High</i>	<i>Low</i>
<b>Machine (Non-Aerosol)</b>	<i>Pressure used to dispense</i>	<i>Moderate</i>	<i>Good</i>	<i>High</i>	<i>Low</i>

## Notes on Coating Application

- Precision, machine dispensing eliminates the need for most masking/protecting of certain components.
- Coating material contains a UV tracer, so blacklights are used to review coverage.
- Oven drying is quicker than air drying and ideal for two-sided applications, but air drying produces less bubbles. Also, forced drying allows better venting for fumes and odors.
- Keep-out areas can be protected with boots or masking tape. Note that taping is a manual, labor-intensive process, and custom boots can reduce labor cost in higher volume applications.

## What We Look for in Our Customers

- Knowledge of what you are trying to protect the electronic assembly from.
- Requirements of thickness, keep-out areas, and acceptance criteria.

For more support in coating selection or to discuss options for quick-turn or production PCBAs, contact us @ [info@npi-plus.com](mailto:info@npi-plus.com) or 262-458-1003.